Globalmediapro Fantail LS1 Lip Sync Corrector

Operation Manual

Table of Contents

1.	Introduction						
2.							
3.	Packag	e Contents	1				
4.	Feature	s	1				
5.	. Specifications						
	6.1 li	nput Audio Reference Level	2				
6.	Operati	on Controls and Functions	3				
	6.1	Top Panel	3				
	6.2	Left Panel	3				
	6.3	Right Panel	3				
	6.4	Front Panel	4				
	6.5	Rear Panel	4				
7.	Connec	ction and Installation	5				

1. Introduction

The L/R In-Out Lip SYNC Corrector is a compact device that corrects audio delays between audio and video. When distributing video over long distances through multiple devices like distribution amplifiers and set top boxes there can sometimes be a noticeable delay which results in audio being played before the video. This gadget lets you manually adjust the audio delay from 0 \sim 300 ms so you can perfectly synchronize your audio and video, so when it reaches the display your media is synched and ready to go. The Lip SYNC Corrector is an affordable and compact device that when placed beside your display greatly enhances your home audio experience.

2. Applications

- Home Theater
- Cable TV
- Set-Top-Box
- Showroom display

3. Package Contents

- Lip SYNC Corrector
- 5V / 1A Power Adaptor
- Operation Manual

4. Features

- Sample Rates 48 kHz
- Analog to analog signal bypass
- Low power consumption
- Up to 24 bit resolution

5. Specifications

Power Supply 5V / 1A DC (US/EU standards, CE/FCC/UL certified) ESD Protection Human body model: \pm 8kV (air-gap discharge)

± 6kV (contact discharge)

Dimensions (mm) 55.6 (W) x 47.5 (D) x 23.5 (H)

Weight(g) 32 Chassis Material Plastic Silkscreen Color White

Operating Temperature $0^{\circ}\text{C} \sim 40^{\circ}\text{C} / 32^{\circ}\text{F} \sim 104^{\circ}\text{F}$ Storage Temperature $-20^{\circ}\text{C} \sim 60^{\circ}\text{C} / -4^{\circ}\text{F} \sim 140^{\circ}\text{F}$

Power Consumption 0.5 W


Relative Humidity 20 ~ 90% RH (non-condensing)

5.1 Input Audio Reference Level

Input Level	Output Level	THD+N	Frequence Response	SNR	Crosstalk
2 Vrms	2.0 Vrms	<0.01%	±0.5dB 20Hz~20KHz	>80dB	<-70dB


6. Operation Controls and Functions

6.1 Top Panel




① POWER LED: The LED will turn blue when the power is connected.

6.2 Left Panel




① L/R IN: These jacks are to connect with input sources such as DVD/Blu-Ray players using stereo cables in order to receive an audio signal.

6.3 Right Panel




① L/R OUT: These jacks are where you connect an output stereo cable to an amplifier, speaker or TV so you can output audio.

6.4 Front Panel



① Lip SYNC switch: This switch has eight settings that allow users to set the audio output delay from 0~300 milliseconds in order to have perfectly synched audio and video.

6.5 Rear Panel



① DC 5V: This slot is where you plug the 5V DC power supply into the unit and connect the adaptor to an AC outlet.

7. Connection and Installation

